Yellow wire from MTX/L (Analog-1 out)
(Optional) brown wire from MTX/L (NBsim)
Red wire from MTX/L (+12v)
Black wire from MTX/L (Ground)
Connected to ECU Chassis (ground)
This connector optional for stock NBO2 sensor
GND
WBO2
N/C
TO ST2
WBO2
SIG GND
BLUE NBSM
RED +12
PWR GND
FROM NBO2 SENSOR (IF FITTED)
TO HD HARNESS
PIN 1 (BLU) = NBO2
PIN 2 (RED) = 12V
PIN 3 (BLK) = GND
GROUND POINT *
* CONNECT TO ISOLATED CLEAN GROUND POINT
E.G. ECU CHASSIS OR FLOORBOARD BOLT W/ PAINT REMOVED
2013-04-01
JIM GORENMAN